



















Power on, LED display on with Time and Temperature.

## TIME

1. Press  turn to time mode
2. Long press  when the time blink
3. the display panel will shows 12H mode or 24H mode
4. Press   to change mode
5. Press  to choose the mode you like.If choose 12H mode,then "PM"will light up at the left corner of screen
6. Press   to adjust the Hour first
7. Press  to determine the Hour and minutes will blink
8. Press   to adjust the minutes
9. Press  to determine the minutes


## YEAR & DATE




1. Press  turn to date mode
2. Long press  when the year blink
3. press   to change number
4. Press  to determine the year and month will blink
5. Press  to determine the month and date will blink
6. Press  to determine the date

## ALARM CLOCK

"-- A1" means alarm clock close ."00A1" means alarm clock open

Press   to open or close.

1. Press  turn to clock "-- A1" / "-- A2" / "-- A3"

2. Long press  when the time blink
3. Turn to Time adjustment
4. Press  to determine the clock
5. Then  will light up at the left corner of screen
6. While It's time for Alarm, it will automatically return to the Alarm mode with buzzer ringing and Alarm dot keep blinking. Press any button to stop the sound. If no operation on the button, the sound will stop after 60 seconds, the dot will not disappear.

## TEMPERATURE

Press  for 2 seconds to switch between Fahrenheit/Celsius.

## POWER-Saving

Turn on/off the power-saving function by pressing the "DOWN" button. (ON with display oNSd and OFF shows --Sd). Press twice to switch Standby or Power saving status.

This function is base on date adjustment.

1. Press DOWN button, choose DP--1/DP--2/DP--3 you need
2. Press MODE button to date mode and long press mode button when the year is blink, stop your operation
  - A: If step 1 is DP--1, then it will return directly to Time mode.
  - B: If step 1 is DP--2, then it will display the date have been set.
  - C: If step 1 is DP--3, then it will return to date, and return to the Time mode after 4 seconds.

DP--3 could keep time always.